






## WindMSG Tutorial #4 (Writing to Bit Memory)



### WINDMSG TUTORIAL PART- 4



#### WRITING TO BIT MEMORY

























## END OF WINDMSG TUTORIAL - PART 4

Now save the program and download it to HG1X unit. After downloading press "F1" key on HG1X unit to write to Output#0 (Q0) of the PLC.